

Installation Instructions



1. Begin by unfolding the berm, spreading it out evenly on your desired surface.
2. Place the brackets along the sides of the berm, preparing them for the next step of installation.
3. Insert an L-bracket into each of the corner pockets. As you do so, gently lift the berm to ensure the bracket slides smoothly into place, positioning it beneath the berm.
4. Continue to fill each of the remaining pockets with an L-bracket, ensuring a secure and stable setup.

NOTES

For Drive-in Berm Users

- If utilizing the berm as a drive-in option, first install brackets on three sides, leaving one of the shorter sides open for vehicle entry.
- Drive the vehicle into the berm, utilizing Track Guards to safeguard the berm during this process.
- Once the vehicle is inside, proceed to complete the setup by adding brackets to the fourth wall.

Ground Cover and Track Guard Users

- If using a Ground Cover, lay it out flat on the ground prior to unfolding the berm, placing it between the ground and the berm.
- After establishing the initial three walls, position Track Guards inside the berm, ensuring they run parallel to the longer side of the berm.

Questions? Call Us 1.888.SOCK.911

WARNING

The machine should always be OFF with the key removed during each step of the installation and removal of this product.